# Re-pack AQM

Written By: Tanya Taylor

Step 1 — Prepare AQM and crate

- Remove the gas inlet, particle monitor inlet and any third-party sensor from your AQM 65.

- Insert two of the foam cross-bracing pads into the crate.

Step 2 — Position AQM

- Carefully position the AQM 65 into the crate so the two supporting bolts at the end of the crate go through the AQM's mounting brackets.

This document was generated on 2022-01-27 03:43:27 PM (MST).

© 2022

support.aeroqual.com/

Page 2 of 3

Step 3 — Finish bracing

- Insert the remaining cross-bracing pads to stabilize the packing and prevent movement during transport.

- Screw the case together with M4 Philips head screws.

- You're now ready to transport your AQM 65.

For further support, contact Technical Support.

This document was generated on 2022-01-27 03:43:27 PM (MST).

© 2022

support.aeroqual.com/

Page 3 of 3