
aeroqual

Unpack monitor

Written By: Tanya Taylor



Step 1 — Shipping carton



- The monitor is shipped in a cardboard carton with moulded protective inserts.
- The dimensions of the carton are 62cm (length) x 32cm (width) x 55cm (height).
- The weight of the carton is less than 14 kg (30.8 lbs).
- Additional components such weather or noise sensors are shipped in separate boxes.

Step 2 — Inspect for damage



- Examine the ShockWatch label on the side of the shipping carton.
- If the label's glass indicator is red, still accept the shipment and make notification of the indicator's status on the delivery receipt.
- Open the carton and inspect the monitor for damage.
- If damage is discovered:
 - Leave the monitor in its original packaging and request immediate inspection from the carrier (within 3 days for international delivery or 5 days for domestic).
 - Contact Aeroqual or your representative immediately.

Step 3 — Check parts



- Verify the serial number label on the documentation matches the serial label on the monitor. Note: The label is inside the monitor on the bottom right side.
- Verify all components have been shipped as per the packing slip.
- Contact Aeroqual or your representative if you suspect any parts are missing.

For further support, contact <u>Technical Support</u>.