aeroqual

1. Setup checklist

Written By: Tanya Taylor



INTRODUCTION

Use this checklist to complete the set up tasks for your handheld monitor in the correct order.

Step 1 — Unpack monitor



• Open your Aeroqual box and verify all components have been shipped.

Step 2 — Connect battery




 Insert the connector on the battery into the socket at the base of the monitor.

Step 3 — Charge battery




• Use the 12VDC AC/DC lithium smart charger to fully charge the battery.

Step 4 — Connect sensor head



- <u>Connect your sensor head.</u>
- If you also bought a temperature and relative humidity sensor, connect that.

Step 5 — Power on and warm up



• Turn on the monitor and wait for the sensor head to warm up.

For further support, contact <u>Technical Support.</u>