




Unpack monitor

Written By: StJohn Vuetilovoni




Step 1 — Unpack monitor



- Open your Aeroqual box and verify all components have been shipped as per the packing slip.
- A 12VDC AC/DC lithium smart charger and a country designated power plug.
- Sensor head if ordered (depending on the quantity, they may or may not be packed in the box with the monitor).
- A USB to monitor cable and a two-way PS2 adapter cable (Series 500 only).
- Contact Aeroqual or your representative if you suspect any parts are missing.

Step 2 — Identify buttons



 The number of buttons on your handheld monitor vary depending on model.

- **Series 200** has 2 buttons:
 - **Power** = Power on/off and menu scroll.
 - **Enter** = Menu and confirm selection
- **Series 300** and **Series 500** have 3 additional buttons:
 - **Alarm mute**
 - **Scroll up**
 - **Scroll down**

For further support, contact [Technical Support](#).