



Mounting

How to mount the Aeroqual Ranger.

Written By: StJohn Vuetilovoni



Step 1 — Ranger Mounting



- i** The Aeroqual Ranger™ contains a 1/4-20 UNC threaded fitting that can be used to secure the instrument to mounting solutions such as tripods.
- Obtain a mounting solution, such as a tripod, with a 1/4 " thread mount.
 - Locate the fitting on the back of the instrument.
 - Secure Ranger by screwing the mounting solution into the back of the instrument.

For further support, contact Aeroqual Support.