


Download data from monitor

Written By: StJohn Vuetilovoni





INTRODUCTION


Use this guide to download data stored in the memory of your Series 500 monitor to your PC. It assumes you have already <u>installed the monitor's configuration software</u>, <u>downloaded the cable driver</u> and <u>connected your monitor to a PC</u>.

Note: You need Version 6.5 or higher of the Aeroqual software for the Series 500.

Step 1 — Check logging indicator









- When data logging is active, a triangle appears on the main display screen.
- A full triangle indicates the memory is full and needs downloading to a PC.
- A filling triangle indicates that some data is stored. Note: The triangle fills up in 10% increments.
- An empty triangle indicates no data is stored.

Step 2 — Start download





- <u>Launch the Aeroqual S500 software</u> and select **File > Download Logged Data** from the menu bar. Alternatively, click the second icon on the toolbar (download).
- A data download progress bar shows while the data is downloading.
- The LED inside the USB cable connection should also flash indicating data transfer.

Step 3 — Troubleshoot issues



This document was generated on 2022-01-05 11:58:34 AM (MST).

- If for any reason, the data download doesn't complete:
 - Turn off the monitor to prevent any data loss.
 - Delete what data has been downloaded.
 - Close then reopen the Series 500 software and repeat the download.
- For any other download issues, <u>see</u> this troubleshooting page.

Step 4 — Clear log



- Downloaded data isn't automatically cleared from the monitor's memory.
- To clear the log, do this <u>via the</u> handheld monitor itself.

Step 5 — Restart logging



- The data download process automatically stops logging on the handheld monitor.
- To restart logging, do this via the handheld monitor itself.

Step 6 — Video of steps



- For extra help, watch our video.
- i This video includes the data download process as well as data export.

For further support, contact **Technical Support**.